



TENSION TECHNOLOGY INTERNATIONAL

Consultants in Flexible Tension Member Systems

OPTIMOOR INSTALLATION

Optimoor is a 32-bit application and will run under all MS Windows including 64-bit operating systems.

First copy the entire contents including subfolders into the folder you choose to install OPTIMOOR. Then run SETUP.EXE by double clicking in this folder. If the installation generates an error due to a conflict with an existing support file, the program may still run anyway. Alternatively, conflicts may be avoided by simply copying all the files from the Support sub-folder into your OPTIMOOR folder and the program should run without system registration.

Under Vista and Windows 7, the Optimoor help file will not work unless the help engine Winhlp32.exe has previously been installed. If not, you should click on one of the Help patch files to install it (Vista Help patch or Windows 7 Help patch). There are different files for 32-bit and 64-bit systems. Alternatively go to <http://www.microsoft.com/downloads/details.aspx?FamilyID=6ebcfad9-d3f5-4365-8070-334cd175d4bb&displaylang=en> where you can get more information. You should also copy the support file ibfs32.dll into the folder with Optimoor.exe.

A common fault on first running is absent text, or text not displaying correctly. This is usually due to the absence of one of the three font files. These files (identified by their extension .TTF) in the Support folder should be copied into the Windows\Fonts system folder if not already there. You should reboot after this operation.

July 2011

TENSION TECHNOLOGY INTERNATIONAL

Alan Ractliffe (worldwide except American continent)
ractliffe@tensiontech.com

John Flory (American continent)
email: flory@tensiontech.com